

91-21-31

SPLICE LIST

91-21-31
SPICE LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
EFFECTIVE PAGES			SP00600 cont.			SP03400 cont.		
	1	Nov 12/2012	R	2	Nov 12/2012	R	2	Nov 12/2012
	2	BLANK	R	SP00700	1 Nov 12/2012	R	3	Nov 12/2012
R SP00000	1	Nov 12/2012	R	SP00800	1 Nov 12/2012	R	4	Nov 12/2012
R	2	Nov 12/2012	R		2 Nov 12/2012	R SP03500	1	Nov 12/2012
R	3	Nov 12/2012	R		3 Nov 12/2012	R SP03700	1	Nov 12/2012
R	4	Nov 12/2012	R		4 Nov 12/2012	R SP03800	1	Nov 12/2012
R SP00100	1	Nov 12/2012	R		5 Nov 12/2012	R SP04000	1	Nov 12/2012
R	2	Nov 12/2012	R SP00900	1	Nov 12/2012	R SP04600	1	Nov 12/2012
R	3	Nov 12/2012	R SP01000	1	Nov 12/2012	R SP05000	1	Nov 12/2012
R	4	Nov 12/2012	R SP01100	1	Nov 12/2012		2	BLANK
R	5	Nov 12/2012	R		2 Nov 12/2012			
R SP00200	1	Nov 12/2012	R SP01200	1	Nov 12/2012			
R	2	Nov 12/2012	R SP01500	1	Nov 12/2012			
R	3	Nov 12/2012	R SP01700	1	Nov 12/2012			
R SP00300	1	Nov 12/2012	R SP01800	1	Nov 12/2012			
R	2	Nov 12/2012	R		2 Nov 12/2012			
R	3	Nov 12/2012	R SP01900	1	Nov 12/2012			
R SP00400	1	Nov 12/2012	R SP02000	1	Nov 12/2012			
R	2	Nov 12/2012	R SP02100	1	Nov 12/2012			
R	3	Nov 12/2012	R SP02200	1	Nov 12/2012			
R	4	Nov 12/2012	R SP02800	1	Nov 12/2012			
R SP00500	1	Nov 12/2012	R SP02900	1	Nov 12/2012			
R	2	Nov 12/2012	R SP03000	1	Nov 12/2012			
R	3	Nov 12/2012	R SP03100	1	Nov 12/2012			
R	4	Nov 12/2012	R SP03200	1	Nov 12/2012			
R	5	Nov 12/2012	R SP03300	1	Nov 12/2012			
R SP00600	1	Nov 12/2012	R SP03400	1	Nov 12/2012			

A = Added, R = Revised, D = Deleted, O = Overflow

SPICE LIST

D280A108

EFFECTIVE PAGES

Page 1
Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
I SP00010		394/178/L047					ALL
I	W5110	0510	20		S	29-11-12	ALL
I	W5230	0503	18		S	29-11-12	YC051-YL968, YN231-YN236, YN501-YR323, YR325-YR328
I SP00012		394/195/R044					ALL
I	W6128	0503	18		S	29-11-12	YC051-YL968, YN231-YN236, YN501-YR323, YR325-YR328
I	W6410	0510	20		S	29-11-12	ALL
I SP00014		//					ALL
I SP00016		255/273/R018					ALL
I SP00020		//					ALL
I SP00028		428/296/R020					ALL
I	W5726	0584	20		S	49-62-11	ALL
I	W6172	0511	20		S	49-62-11	ALL
I SP00030		428/296/R020					ALL
I	W5726	0598	10		S	49-62-11	ALL
I	W6172	6003	10		S	49-62-11	ALL
I SP00032		//					ALL
I SP00034		//					ALL
I SP00036		//					ALL
I SP00038		//					ALL
I SP00040		//					ALL
I SP00042		//					ALL
I SP00044		//					ALL
I SP00046		//					ALL
I SP00047		1040/194/L005					ALL
I	W7359	3502R	20		9	23-41-11	ALL

SPLICE LIST

D280A108

91-21-31

Section SP00000

Page 1

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00047		1040/194/L005 (continued)					ALL
	W7359	3502Z				23-41-11	ALL
	W7359	A-A			9	23-41-11	ALL
SP00048		//					ALL
SP00049		1040/194/L005					ALL
	W7359	3502B	20		9	23-41-11	ALL
	W7359	A-B			9	23-41-11	ALL
SP00051		1040/194/L005					ALL
	W7359	3502Y	20		9	23-41-11	ALL
	W7359	A-C			9	23-41-11	ALL
SP00052		//					ALL
SP00054		1085/265/L001					ALL
	W4134	1013	20		9	31-53-11	YC053-YR328
	W4134	A-C			9	31-53-11	YC053-YL955, YN231-YN235
	W4134	D-C			9	31-53-11	YL956-YL999, YN236-YR328
	W6134	0513	20		9	31-53-11	YC051-YC052
	W6134	A-C			9	31-53-11	YC051-YC052
SP00056		1085/265/L001					ALL
	W4134	1014	20		9	31-53-11	YC053-YR328
	W4134	A-B			9	31-53-11	YC053-YL955, YN231-YN235
	W4134	A-D			9	31-53-11	YL956-YL999, YN236-YR328
	W4134	B-B			9	31-53-11	YC053-YL955, YN231-YN235
	W4134	B-D			9	31-53-11	YL956-YL999, YN236-YR328
	W6134	0514	20		9	31-53-11	YC051-YC052
	W6134	A-B			9	31-53-11	YC051-YC052
	W6134	B-B			9	31-53-11	YC051-YC052
SP00058		1085/265/L001					ALL
	W4134	A-F			9	31-53-11	YC053-YL955, YN231-YN235
	W4134	B-C			9	31-53-11	YC053-YL955, YN231-YN235
	W4134	C-C			9	31-53-11	YL956-YL999, YN236-YR328
	W4134	D-F			9	31-53-11	YL956-YL999, YN236-YR328
	W6134	A-F			9	31-53-11	YC051-YC052
	W6134	B-C			9	31-53-11	YC051-YC052

SPLICE LIST

D280A108

91-21-31

Section SP00000

Page 2

Nov 12/2012

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
I SP00060		//					ALL
I SP00064		//					ALL
I SP00066		//					ALL
I SP00067		265/184/L065					ALL
I SP00068		//					ALL
I SP00070		232/271/0					ALL
I	W2218	5560	18		S	33-14-12	ALL
I	W2218	A-AA			S	33-14-12	ALL
I SP00072		232/271/0					ALL
I	W2218	5561	18		S	33-14-12	ALL
I	W2218	A-AB			S	33-14-12	ALL
I SP00078		250/267/L029					ALL
I SP00081		258/194/L008					YL951-YR328
I	W2413	0059	24		S	23-27-31	YL951-YR328
I	W2415	0059	24		S	23-27-31	YL951-YR328
I	W2417	0013	24		S	MULTI	YL951-YL954, YN231-YN235
I	W2417	0013	24		S	SPARE	YN501-YR328
I	W2417	0059	24		S	23-27-31	YL951-YR328
I	W3323	0059	24		S	23-27-31	YL951-YR328
I SP00082		236/210/R038					ALL
I SP00083		258/194/L008					YL951-YR328
I	W2413	0055	24		S	23-27-31	YL951-YR328
I	W2415	0055	24		S	23-27-31	YL951-YR328
I	W2417	0055	24		S	23-27-31	YL951-YR328
I	W3323	0058	24		S	23-27-31	YL951-YR328
I	W3323	0059	24		S	23-27-31	YL951-YR328
I SP00084		//					ALL

SPLICE LIST

D280A108

91-21-31

Section SP00000

Page 3

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
I SP00086		//					ALL
I SP00087		258/194/L008					YD158-YR328
I	W2413	0054	24		S	23-27-31	YD158-YR328
I	W2415	0054	24		S	23-27-31	YD158-YR328
I	W2417	0054	24		S	23-27-31	YD158-YR328
I	W3323	0055	24		S	23-27-31	YD158-YR328
I	W3323	0058	24		S	23-27-31	YL951-YR328
I SP00088		//					ALL
I SP00089		209/206/L023					ALL
I	W0145	0001	20		S	27-32-11	ALL
I	W2201	0020	20		S	27-32-11	ALL
I SP00091		209/206/R023					ALL
I	W0147	0001	20		S	27-32-21	ALL
I	W2231	0016	20		S	27-32-21	YC051-YN236, YN501-YR328
SP00092		891/297/L024					YC051-YC053
	W5124	0532	18		S	27-31-11	YC051-YC053
	W6134	0537	18		S	27-31-11	YC051-YC053
SP00094		891/297/L024					YC051-YC053
	W5124	0533	18		S	27-31-11	YC051-YC053
	W6134	0530	18		S	27-31-11	YC051-YC053
I SP00098		586/200/R036					ALL

SPLICE LIST

D280A108

91-21-31

Section SP00000

Page 4 End

Nov 12/2012

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00102		358/201/L020					ALL
	W6110	0020	20		S	33-34-11	ALL
	W6110	0030	20		S	33-34-11	ALL
	W6110	B-A			S	33-34-11	ALL
SP00104		356/202/R013					ALL
	W6110	0030	20		S	33-34-11	ALL
	W6110	0040	20		S	33-34-11	ALL
	W6110	B-B			S	33-34-11	ALL
SP00110		727+2/198/R050					YC059-YR328
	W5124	0520	20		S	27-41-12	YC059-YR328
	W5224	0518	20		S	27-41-12	YC059-YR328
SP00112		663/165/R008					ALL
	W7122	0522	18		9	29-23-11	YC051-YR323, YR325-YR328
	W8122	0510	20		9	29-23-11	YC051-YD158, YL951-YR323, YR325-YR328
SP00113		1085/232/L018					ALL
	W3381	0005	20		9	22-13-11	YC051-YC052
	W3381	A-1			9	22-13-11	YC051-YC052
	W3391	1005	20		9	22-13-11	YC053-YR328
	W3391	A-1			9	22-13-11	YC053-YR328
SP00114		727+2/199/R049					YC059-YR328
	W5124	0522	18		S	27-41-12	YC059-YR328
	W5224	0516	20		S	27-41-12	YC059-YR328
SP00115		1085/232/L018					ALL
	W3381	0010	20		9	22-13-11	YC051-YC052
	W3381	A-3			9	22-13-11	YC051-YC052
	W3391	1010	20		9	22-13-11	YC053-YR328
	W3391	A-3			9	22-13-11	YC053-YR328
SP00116		346/224/L017					YN231-YN260
SP00117		1085/232/L018					ALL
	W3381	0004	20		9	22-13-11	YC051-YC052
	W3381	B-1			9	22-13-11	YC051-YC052
	W3391	1004	20		9	22-13-11	YC053-YR328

SPLICE LIST

D280A108

91-21-31

Section SP00100

Page 1

Nov 12/2012

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00117		1085/232/L018 (continued)					ALL
	W3391	B-1			9	22-13-11	YC053-YR328
SP00118		346/224/L017					YN231-YN260
SP00119		1085/232/L018					ALL
	W3381	0012	20		9	22-13-11	YC051-YC052
	W3381	B-3			9	22-13-11	YC051-YC052
	W3391	1012	20		9	22-13-11	YC053-YR328
	W3391	B-3			9	22-13-11	YC053-YR328
SP00124		727+2/199/R049					YC059-YR328
	W5124	0523	20		S	27-41-12	YC059-YR328
	W5224	0500	20		S	27-41-12	YC059-YR328
SP00132		//					ALL
SP00133		334/308/L020					ALL
	W3144	2401R	22		S	23-31-02	ALL
	W3150	2699R	22		S	23-31-02	ALL
	W3329	2006R	22		S	23-31-02	ALL
	W4250	2699R	22		S	23-31-03	ALL
SP00134		//					ALL
SP00135		335/290/L020					ALL
	W3144	2401B	22		S	23-31-02	ALL
	W3150	2699B	22		S	23-31-02	ALL
	W3329	2006B	22		S	23-31-02	ALL
	W4250	2699B	22		S	23-31-03	ALL
SP00136		//					ALL
SP00144		281/186/R021					ALL
SP00146		281/186/21					ALL
SP00152		1085/265/L014					ALL
	W3381	A-6			9	27-41-12	YC051-YC052
	W3391	A-6			9	27-41-12	YC053-YR328

SPLICE LIST

D280A108

91-21-31

Section SP00100

Page 2

Nov 12/2012

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00152		1085/265/L014 (continued)					ALL
	W4222	1006	18		9	27-41-12	YC053-YN236, YN501-YR328
	W6222	0506	18		9	27-41-12	YC051-YC052
SP00154		1085/265/L014					ALL
	W4222	1005	18		9	27-41-12	YC053-YN236, YN501-YR328
	W4222	A-E			9	27-41-12	YC053-YN236, YN501-YR328
	W4222	A-F			9	27-41-12	YC053-YN236, YN501-YR328
	W6222	0505	18		9	27-41-12	YC051-YC052
	W6222	A-E			9	27-41-12	YC051-YC052
	W6222	A-F			9	27-41-12	YC051-YC052
SP00156		1085/265/L014					ALL
	W3381	A-4			9	27-41-12	YC051-YC052
	W3391	A-4			9	27-41-12	YC053-YR328
	W4222	1003	20		9	27-41-12	YC053-YN236, YN501-YR328
	W6222	0503	20		9	27-41-12	YC051-YC052
SP00157		E003-01/ /					YC053-YR328
	W0311	2029R	24		W	31-62-15	YC053-YR328
	W0311	2171R	24		W	31-62-15	YC053-YR328
	W0313	2669R	24		W	31-62-15	YC053-YR328
SP00158		1085/265/L014					ALL
	W4222	1001	20		9	27-41-12	YC053-YN236, YN501-YR328
	W4222	A-J			9	27-41-12	YC053-YN236, YN501-YR328
	W6222	0501	20		9	27-41-12	YC051-YC052
	W6222	A-J			9	27-41-12	YC051-YC052
SP00159		E003-01/ /					YC053-YR328
	W0311	2029B	24		W	31-62-15	YC053-YR328
	W0311	2171B	24		W	31-62-15	YC053-YR328
	W0313	2669B	24		W	31-62-15	YC053-YR328
SP00160		1085/265/L014					ALL
	W4222	1002	20		9	27-41-12	YC053-YN236, YN501-YR328
	W4222	A-K			9	27-41-12	YC053-YN236, YN501-YR328
	W6222	0502	20		9	27-41-12	YC051-YC052
	W6222	A-K			9	27-41-12	YC051-YC052

SPLICE LIST

D280A108

91-21-31

Section SP00100

Page 3

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00161		E003-01/ /					YC053-YR328
	W0311	2029Z			W	31-62-15	YC053-YR328
	W0311	2171Z			W	31-62-15	YC053-YR328
	W0313	2669Z			W	31-62-15	YC053-YR328
SP00162		//					ALL
SP00164		259/ /					ALL
SP00165		258/194/L008					YD158-YR328
	W2413	0040	18		S	23-12-11	YD158-YR328
	W2651	0015	16		S	23-12-11	YD158-YR328
	W2651	0026	16		S	23-12-11	YD158-YR328
SP00166		//					ALL
SP00167		269.8/199/R040					YD158-YR328
	W2383	0016	16		9	23-12-21	YD158-YR328
	W2383	0036	16		9	23-12-21	YD158-YR328
	W2415	0040	18		9	23-12-21	YD158-YR328
SP00168		//					ALL
SP00170		727+2/199/R049					YC059-YR328
	W5124	0517	20		S	27-41-12	YC059-YR328
	W5224	0523	20		S	27-41-12	YC059-YR328
SP00172		IRSS/219/					ALL
	W7230	6002	18		9	28-42-11	YC051-YR323, YR325-YR328
	W7230	6003	20		9	28-42-11	YC051-YR323, YR325-YR328
	W7230	A-AA			9	28-42-11	YC051-YR323, YR325-YR328
SP00174		IRSS/219/					ALL
	W7230	6001	20		9	28-42-11	YC051-YR323, YR325-YR328
	W7230	B-BB			9	28-42-11	YC051-YR323, YR325-YR328
SP00178		//					ALL
SP00180		//					ALL

SPLICE LIST
D280A108

91-21-31
Section SP00100
Page 4
Nov 12/2012



	Splice No.	Bundle	Station / WL / BL		GA	CO	Type	Diagram	Effectivity
			Wire No.						
I	SP00182		//						ALL
I	SP00184		//						ALL
I	SP00188		220/210/R039						ALL
I	SP00190		//						ALL
I	SP00192		//						ALL
I	SP00194		//						ALL

SPLICE LIST

D280A108

91-21-31

Section SP00100

Page 5 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00202		500I+17/171/L049					YC051-YL999, YR301-YR328
SP00202		500D+7/170/L049					YN231-YN501
	W5164	1301	20		S	28-21-11	YC051-YN236, YN501-YR328
	W5164	1301Z				28-21-11	YC051-YN236, YN501-YR328
	W5230	6011	18		S	28-21-11	YC051-YL968, YN231-YN236, YN501-YR323, YR325-YR328
SP00204		* / /					ALL
SP00206		749/297/L023					ALL
SP00210		990/181/L018					ALL
	W6248	5501	20		9	30-71-11	YC051-YN236, YN501-YR328
	W6248	E-B			9	30-71-11	YC051-YN236, YN501-YR328
SP00212		990/181/L018					ALL
	W6248	5514	20		9	30-71-11	YC051-YN236, YN501-YR328
	W6248	E-C			9	30-71-11	YC051-YN236, YN501-YR328
SP00214		395/188/R010					ALL
SP00216		/ /					ALL
SP00218		/ /					ALL
SP00220		/ /					ALL
SP00222		/ /					ALL
SP00224		/ /					ALL
SP00226		858/170/L032					ALL
	W6248	5544	20		9	30-71-11	YC051-YN236, YN501-YR328
	W6248	F-A			9	30-71-11	YC051-YN236, YN501-YR328
SP00228		858/170/L032					ALL
	W6248	5545	20		9	30-71-11	YC051-YN236, YN501-YR328
	W6248	F-B			9	30-71-11	YC051-YN236, YN501-YR328
SP00230		915/168/R002					ALL
	W6248	5546	20		9	30-71-11	YC051-YN236, YN501-YR328

SPLICE LIST
D280A108

91-21-31
Section SP00200
Page 1
Nov 12/2012

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00230		915/168/R002 (continued)					ALL
	W6248	G-A			9	30-71-11	YC051-YN236, YN501-YR328
SP00232		915/168/R002					ALL
	W6248	5547	20		9	30-71-11	YC051-YN236, YN501-YR328
	W6248	G-B			9	30-71-11	YC051-YN236, YN501-YR328
SP00238		959/178/R008					ALL
	W6248	5552	20		9	30-71-11	YC051-YN236, YN501-YR328
	W6248	H-A			9	30-71-11	YC051-YN236, YN501-YR328
SP00240		959/178/R008					ALL
	W6248	5551	20		9	30-71-11	YC051-YN236, YN501-YR328
	W6248	H-B			9	30-71-11	YC051-YN236, YN501-YR328
SP00242		959/178/R008					ALL
	W6248	5564	20		9	30-71-11	YC051-YN236, YN501-YR328
	W6248	I-A			9	30-71-11	YC051-YN236, YN501-YR328
SP00244		959/178/R008					ALL
	W6248	5565	20		9	30-71-11	YC051-YN236, YN501-YR328
	W6248	I-B			9	30-71-11	YC051-YN236, YN501-YR328
SP00251		225/220/R042					ALL
SP00252		891/176/R037					ALL
	W5726	0538	22		S	49-62-11	ALL
	W5728	0504	20		S	49-62-11	ALL
SP00253		225/220/R042					ALL
SP00254		891/176/R037					ALL
	W5726	0540	22		S	49-62-11	ALL
	W5728	0502	20		S	49-62-11	ALL
SP00255		225/220/R042					ALL
SP00256		891/176/R037					ALL
	W5726	0542	22		S	49-62-11	ALL
	W5728	0501	20		S	49-62-11	ALL

SPLICE LIST

D280A108

91-21-31

Section SP00200

Page 2

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
I SP00258		891/176/R037					ALL
I	W5726	0544	22		S	49-62-11	ALL
I	W5728	0503	20		S	49-62-11	ALL
I SP00260		599/220/L070					YC051-YL999, YR301-YR328
I	W3142	5545	20		9	21-42-11	YC051-YL999, YR301-YR328
I	W3142	E-B			9	21-42-11	YC051-YL999, YR301-YR328
I SP00262		//					ALL
I SP00264		//					ALL
I SP00266		//					ALL
I SP00268		//					ALL
I SP00270		599/220/L070					YC051-YL999, YR301-YR328
I	W3142	5544	20		9	21-42-11	YC051-YL999, YR301-YR328
I	W3142	E-A			9	21-42-11	YC051-YL999, YR301-YR328
I SP00272		233/265/L025					YC070-YR328
I	W2102	5528	20		S	33-17-11	YD152-YR328
I	W2102	5530	20		S	33-17-11	YD152-YR328
I	W2102	B-BG			S	33-17-11	YD152-YR328
I SP00280		OFSS380/ /					ALL
I	W1664	1035	20		9	28-44-11	YC051-YD158, YL951-YR328
I	W1664	A-D			9	28-44-11	YC051-YD158, YL951-YR328
I SP00291		388/192/R031					YL968-YL999, YN236-YN260
	W0410	0291	20		W	23-32-21	YL968-YL999, YN236-YN260
	W0411	0313	20		W	23-32-21	YL968-YL999, YN236-YN260

SPLICE LIST
D280A108

91-21-31
Section SP00200
Page 3 End
Nov 12/2012

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00300		237/208/L036					ALL
	W2030	1001	18		S	33-11-31	ALL
	W2030	1001Z				33-11-31	ALL
	W2363	1062	20		S	33-11-31	ALL
	W2363	1062Z				33-11-31	ALL
SP00302		265/280/L01					ALL
	W2114	0025	20		S	33-51-12	YC051-YC052
	W2114	A-AP			S	33-51-12	YC051-YC052
SP00304		269/273/L014					YN231-YN501
SP00318		500I+17/153/R009					YC051-YL999, YR301-YR328
SP00318		500D+17/153/R009					YN231-YN501
	W6128	6011	18		S	28-21-11	YC051-YL968, YN231-YN236, YN501-YR323, YR325-YR328
	W6164	1301	20		S	28-21-11	YC051-YN236, YN501-YR328
	W6164	1301Z				28-21-11	YC051-YN236, YN501-YR328
SP00321		228/209/L000					YC065
SP00321		240/197/L000					YC070-YR328
	W2265	0007	20		9	33-18-62	YC065, YC070-YR328
	W2265	0008	20		9	33-18-62	YC065, YC070-YR328
	W2403	0023	20		9	33-18-62	YC065, YC070-YD157
	W2413	0035	20		9	33-18-62	YD158-YR328
SP00326		668/167/L025					ALL
	W5230	6011	18		9	28-21-11	YC051-YL968, YN231-YN236, YN501-YR323, YR325-YR328
	W7230	6011	18		9	28-21-11	YC051-YR323, YR325-YR328
SP00332		698/191/L062					ALL
	W7126	2222R	20		9	32-64-12	YC051-YL968, YN231-YN236, YN501-YR328
	W7126	A-R			9	32-64-12	YC051-YL968, YN231-YN236, YN501-YR328
SP00334		698/191/L062					ALL
	W7126	2222B	20		9	32-64-12	YC051-YL968, YN231-YN236, YN501-YR328
	W7126	A-B			9	32-64-12	YC051-YL968, YN231-YN236, YN501-YR328
SP00336		//					ALL

SPLICE LIST

D280A108

91-21-31

Section SP00300

Page 1

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
I SP00342		692/192/L062					ALL
I	W7230	2222R	20		9	32-64-11	YC051-YR323, YR325-YR328
I	W7230	A-R			9	32-64-11	YC051-YR323, YR325-YR328
I SP00344		692/194/L061					ALL
I	W7230	2222B	20		9	32-64-11	YC051-YR323, YR325-YR328
I	W7230	A-B			9	32-64-11	YC051-YR323, YR325-YR328
I SP00346		//					ALL
I SP00352		698/196/R061					ALL
I	W8224	2224R	20		9	32-64-12	ALL
I	W8224	A-R			9	32-64-12	ALL
I SP00354		698/196/R061					ALL
I	W8224	2224B	20		9	32-64-12	ALL
I	W8224	A-B			9	32-64-12	ALL
I SP00356		//					ALL
I SP00358		727+2/195/L042					ALL
I	W5032	6001	20		S	28-21-11	ALL
I	W5530	6011	20		S	28-21-11	ALL
I SP00361		250/267/R030					ALL
I SP00362		692/196/R061					ALL
I	W8228	2214R	20		9	32-64-11	ALL
I	W8228	A-R			9	32-64-11	ALL
I SP00363		250/267/R030					ALL
I SP00364		692/196/R061					ALL
I	W8228	2214B	20		9	32-64-11	ALL
I	W8228	A-B			9	32-64-11	ALL
I SP00365		250/267/R030					ALL
I SP00366		//					ALL

SPLICE LIST
D280A108

91-21-31
Section SP00300
Page 2
Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00368		727+2/199/R049					YC059-YR328
	W5124	0524	20		S	27-41-12	YC059-YR328
	W5224	0519	20		S	27-41-12	YC059-YR328
SP00370		727+5/198/R050					YC059-YR328
	W5124	0525	20		S	27-41-12	YC059-YR328
	W5224	0520	20		S	27-41-12	YC059-YR328
SP00372		727+2/199/R049					YC059-YR328
	W5124	0518	18		S	27-41-12	YC059-YR328
	W5224	0525	18		S	27-41-12	YC059-YR328
SP00373		//					YC059-YR328
SP00374		727+2/199/R049					YC059-YR328
	W5124	0519	20		S	27-41-12	YC059-YR328
	W5224	0524	20		S	27-41-12	YC059-YR328
SP00376		727+2/199/R049					YC059-YR328
	W5124	0521	20		S	27-41-12	YC059-YR328
	W5224	0517	20		S	27-41-12	YC059-YR328
SP00390		208/200/R013					ALL
	W6110	0003	20		S	33-34-11	ALL
	W6110	0004	20		S	33-34-11	ALL
	W6110	A-C			S	33-34-11	ALL
SP00392		222/204/R011					ALL
	W6110	0004	20		S	33-34-11	ALL
	W6110	A-B			S	33-34-11	ALL
SP00394		223/206/L005					ALL
	W6110	0002	20		S	33-34-11	ALL
	W6110	0003	20		S	33-34-11	ALL
	W6110	A-A			S	33-34-11	ALL

SPLICE LIST

D280A108

91-21-31

Section SP00300

Page 3 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00411		250/267/R030					ALL
SP00412		937/317/L013					ALL
	W3142	0412	20		S	33-51-22	YC051-YD157, YN231-YN501
	W3142	0414	20		S	33-51-22	YD158-YL999, YR301-YR328
	W3142	0442	20		S	33-51-22	YC051-YD157, YN231-YN501
	W3144	0310	20		S	33-51-22	ALL
SP00413		250/267/R030					ALL
SP00418		533/163/R001					ALL
	W5526	0520	20		9	33-33-11	ALL
	W6230	0522	20		9	33-33-11	YC051-YR323, YR325-YR328
SP00420		533/163/R001					ALL
	W5526	0521	20		9	33-33-11	ALL
	W6230	0521	20		9	33-33-11	YC051-YR323, YR325-YR328
SP00421		OFSS 381/ /					ALL
	W1664	3002R	20		9	23-41-11	YC051-YD158, YL951-YR328
	W1664	3002ZI				23-41-11	YC051-YD158, YL951-YR328
	W1664	A-V			9	23-41-11	YC051-YD158, YL951-YR328
SP00423		OFSS 381/ /					ALL
	W1664	3002Y	20		9	23-41-11	YC051-YD158, YL951-YR328
	W1664	A-W			9	23-41-11	YC051-YD158, YL951-YR328
SP00425		OFSS 381/ /					ALL
	W1664	3002B	20		9	23-41-11	YC051-YD158, YL951-YR328
	W1664	A-U			9	23-41-11	YC051-YD158, YL951-YR328
SP00426		663/165/R008					ALL
	W6128	6011	18		9	28-21-11	YC051-YL968, YN231-YN236, YN501-YR323, YR325-YR328
	W8222	6011	18		9	28-21-11	YC051-YD158, YL951-YL968, YN231-YR328
SP00436		252/237/L048					ALL
	W2102	5503	18		S	33-14-12	ALL
	W2102	5527	18		S	33-14-12	ALL
	W2102	J-JP			S	33-14-12	ALL

SPLICE LIST

D280A108

91-21-31

Section SP00400

Page 1

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
I SP00438		251/238/R048					ALL
I	W2204	5502	18		S	33-14-12	ALL
I	W2204	5504	18		S	33-14-12	ALL
I	W2204	5506	18		S	33-14-12	ALL
I	W2204	D-DP			S	33-14-12	ALL
I SP00452		//					ALL
I SP00458		729/198/R050					ALL
I	W6028	6001	20		S	28-21-11	ALL
I	W6122	6011	20		S	28-21-11	ALL
I SP00460		//					ALL
I SP00462		//					ALL
I SP00464		//					ALL
I SP00465		240/198/L001					YL951-YR328
I	W3319	0054	24		9	31-62-42	YL951-YR328
I	W3709	0003	24		9	31-62-42	YL951-YR328
I SP00469		255.9/194/L9.2					YC051-YD158
I SP00469		256/194/L9					YC060-YC064
	W5110	5502	22		9	21-27-21	YC060-YC064
	W6510	0005	22		9	21-27-21	YC060-YC064
I SP00471		//					YC051-YD158
I SP00471		256/194/L9					YC060-YC064
	W6210	5511	22		9	21-27-21	YC060-YC064
	W6510	0004	22		9	21-27-21	YC060-YC064
I SP00472		371/294/R023					ALL
I	W6122	0508	20		S	29-31-11	ALL
I	W6412	0514	20		S	29-31-11	YC051-YN236, YN501-YR323, YR325-YR328
I SP00474		371/294/R023					ALL
I	W6122	0509	20		S	29-31-11	ALL
I	W6412	0510	20		S	29-31-11	YC051-YN236, YN501-YR323, YR325-YR328

SPLICE LIST

D280A108

91-21-31

Section SP00400

Page 2

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
I SP00476		371/294/R023					ALL
I	W6122	0510	20		S	29-31-11	ALL
I	W6412	0509	20		S	29-31-11	YC051-YN236, YN501-YR323, YR325-YR328
I SP00478		371/294/R023					ALL
I	W6122	0513	20		S	29-23-11	ALL
I	W6412	0515	22		S	29-23-11	YC051-YN236, YN501-YR323, YR325-YR328
I SP00479		408/199/L35					ALL
	W2110	0005	24		9	31-31-15	YC060-YC064
	W2110	0007	24		9	21-25-11	YC060-YC064
	W2110	6044	24		9	31-31-15	YC060-YC064
I SP00480		256/194/L9					ALL
	W5156	5508	22		9	21-27-21	YC060-YC064
	W5156	5532	22		9	21-27-21	YC060-YC064
	W6510	0006	22		9	21-27-21	YC060-YC064
I SP00481		408/199/L35					ALL
	W2110	0006	24		9	31-31-15	YC060-YC064
	W2110	0008	24		9	21-25-11	YC060-YC064
	W2110	6045	24		9	31-31-15	YC060-YC064
I SP00482		/ /					ALL
I SP00484		256/194/L9					ALL
I SP00486		IFSS 149/ /					ALL
I	W1280	2003B	20		9	27-81-21	YC051-YN236, YN501-YR328
I	W1280	K-B			9	27-81-21	YC051-YN236, YN501-YR328
I SP00488		IFSS 149/ /					ALL
I	W1280	2004B	20		9	27-81-21	YC051-YN236, YN501-YR328
I	W1280	L-B			9	27-81-21	YC051-YN236, YN501-YR328
I SP00490		IFSS 168/ /					ALL
I	W1280	2002B	20		9	27-81-21	YC051-YN236, YN501-YR328
I	W1280	J-B			9	27-81-21	YC051-YN236, YN501-YR328

SPLICE LIST
D280A108

91-21-31
Section SP00400
Page 3
Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
I SP00492		IFSS 165/ /					ALL
I	W1280	2001B	20		9	27-81-21	YC051-YN236, YN501-YR328
I	W1280	I-B			9	27-81-21	YC051-YN236, YN501-YR328
I SP00496		749/297/L023					ALL
I SP00498		727A+2.0/297/L023					ALL

SPLICE LIST

D280A108

91-21-31

Section SP00400

Page 4 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
I SP00501		E003-01/ /					YC051-YD170
	W0311	0165	22		W	34-41-11	YC051-YC052
	W0313	0661	22		W	34-41-11	YC051-YC052
	W0313	0663	22		W	34-41-11	YC051-YC052
	W0313	0669	22		W	34-41-11	YC051-YC052
I SP00502		727A+2.0/297/L023					ALL
I	W3381	0020	20		S	22-13-11	YC053-YR328
I	W6134	0547	18		S	27-31-11	YC053-YN236, YN501-YR328
I	W6134	0548	18		S	27-31-11	YC053-YN236, YN501-YR328
I SP00503		727+17/202/L053					YC054-YR328
I	W5124	0508	20		S	27-31-11	YC054-YR328
I	W6124	0527	20		S	27-31-11	YC054-YR328
I SP00504		727A+2.0/297/L023					ALL
I	W5224	0521	20		S	29-23-11	ALL
I	W6134	0517	20		S	29-23-11	YC051-YN236, YN501-YR328
I SP00505		727+17/202/L053					YC054-YR328
I	W5124	0509	20		S	27-31-11	YC054-YR328
I	W6124	0528	20		S	27-31-11	YC054-YR328
I SP00506		1087/266/L014					ALL
	W3381	0017	20		9	22-13-11	YC051-YC052
	W6134	0531	18		9	27-31-11	YC051-YC052
	W6134	0532	18		9	27-31-11	YC051-YC052
I SP00507		E003-01/ /					YC053-YR328
I	W0311	2116R	24		W	34-21-13	YC053-YR328
I	W0311	2169R	24		W	34-21-13	YC053-YR328
I	W0313	2677R	24		W	34-21-13	YC053-YR328
I SP00508		E003-01/ /					YC053-YR328
I	W0311	2116B	24		W	34-21-13	YC053-YR328
I	W0311	2169B	24		W	34-21-13	YC053-YR328
I	W0313	2677B	24		W	34-21-13	YC053-YR328
I SP00509		E003-01/ /					YC053-YR328
I	W0311	2116Z			W	34-21-13	YC053-YR328

SPLICE LIST
D280A108

91-21-31
Section SP00500
Page 1
Nov 12/2012

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00509		E003-01/ / (continued)					YC053-YR328
	W0311	2169Z			W	34-21-13	YC053-YR328
	W0313	2677Z			W	34-21-13	YC053-YR328
SP00518		IFSS-168/ /					ALL
	W1180	2002B	20		9	27-81-11	ALL
	W1180	J-B			9	27-81-11	ALL
SP00520		IFSS-164/ /					ALL
	W1180	2001B	20		9	27-81-11	ALL
	W1180	I-B			9	27-81-11	ALL
SP00522		IFSS-149/ /					ALL
	W1180	2003B	20		9	27-81-11	ALL
	W1180	K-B			9	27-81-11	ALL
SP00524		IFSS-149/ /					ALL
	W1180	2004B	20		9	27-81-11	ALL
	W1180	L-B			9	27-81-11	ALL
SP00530		532/151/R027					ALL
	W6202	1018	20		9	30-71-11	ALL
	W6202	A-AA			9	30-71-11	ALL
SP00532		532/151/R027					ALL
SP00533		347/271/L053					ALL
	W2216	0015	24		9	52-71-11	YC051-YD158
	W3058	0027	24		9	52-71-11	YL951-YR328
	W3058	0028	24		9	52-71-11	YC051-YD158, YL951-YR328
	W3058	A-2			9	52-71-11	YC051-YD158, YL951-YR328
SP00535		347/271/L053					ALL
	W3058	0028	24		9	52-71-11	YC051-YD158, YL951-YR328
	W3058	A-5			9	52-71-11	YC051-YD158, YL951-YR328
SP00536		727+17*/202/L053					ALL
	W5124	0511	20		S	27-31-37	YC051-YC057
	W5124	0511	24		S	27-31-37	YC058-YR328
	W6124	0562	20		S	27-31-37	YC051-YC057

SPLICE LIST

D280A108

91-21-31

Section SP00500

Page 2

Nov 12/2012

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00536		727+17*/202/L053 (continued)					ALL
	W6124	0562	24		S	27-31-37	YC058-YR328
SP00537		347/271/L053					ALL
	W3058	0029	22		9	52-71-11	YC051-YD158, YL951-YR328
	W3058	A-1			9	52-71-11	YC051-YD158, YL951-YR328
	W3058	A-4			9	52-71-11	YC051-YD158, YL951-YR328
SP00538		727+17*/202/L053					ALL
	W5124	0512	20		S	27-31-37	ALL
	W6124	0563	20		S	27-31-37	ALL
SP00539		232/271/0					YD160-YR328
SP00540		727+17*/202/L053					ALL
	W5124	0514	20		S	27-31-37	YC051-YC057
	W5124	0514	24		S	27-31-37	YC058-YR328
	W6124	0564	20		S	27-31-37	YC051-YC057
	W6124	0564	24		S	27-31-37	YC058-YR328
SP00542		727+17*/202/L053					ALL
	W5124	0516	20		S	27-31-37	ALL
	W6124	0506	20		S	27-31-11	ALL
	W6124	0565	20		S	27-31-11	ALL
SP00544		727A+11/297/L023					YC051-YL999, YR301-YR328
	W3142	0232	12		S	33-51-14	YC051-YL999, YR301-YR328
	W4142	0092	12		S	33-51-14	YC051-YL999, YR301-YR328
SP00546		583/297/R024					YC051-YL999, YR301-YR328
	W3142	0341	14		S	33-51-13	YC051-YD157
	W4142	0331	14		S	33-51-13	YC051-YD157
	W4142	0332	14		S	33-51-13	YC051-YD157
SP00554		IFSS 149/ /					ALL
	W1280	2003R	20		9	27-81-21	YC051-YN236, YN501-YR328
	W1280	K-R			9	27-81-21	YC051-YN236, YN501-YR328
SP00556		IFSS 149/ /					ALL
	W1280	2004R	20		9	27-81-21	YC051-YN236, YN501-YR328

SPLICE LIST

D280A108

91-21-31

Section SP00500

Page 3

Nov 12/2012

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00556		IFSS 149/ / (continued)					ALL
	W1280	L-R			9	27-81-21	YC051-YN236, YN501-YR328
SP00558		IFSS 168/ /					ALL
	W1280	2002R	20		9	27-81-21	YC051-YN236, YN501-YR328
	W1280	J-R			9	27-81-21	YC051-YN236, YN501-YR328
SP00560		IFSS 165/ /					ALL
	W1280	2001R	20		9	27-81-21	YC051-YN236, YN501-YR328
	W1280	I-R			9	27-81-21	YC051-YN236, YN501-YR328
SP00570		532/151/R027					ALL
	W6202	A-AB			9	30-71-11	ALL
	W6202	A-AC			9	30-71-11	ALL
SP00572		532/151/R027					ALL
	W6202	5557	20		9	30-71-11	ALL
	W6202	A-AD			9	30-71-11	ALL
SP00573		236/ /					YC060-YC064
	W5156	0403	22		W	31-53-11	YC060-YC064
	W5156	0698	22		W	31-53-11	YC060-YC064
	W5514	5603	22		W	31-53-11	YC060-YC064
SP00575		236/ /					YC060-YC064
	W2508	5508	22		W	21-33-11	YC060-YC064
	W2508	6018	22		W	21-33-11	YC060-YC064
	W5156	0402	22		W	21-33-11	YC060-YC064
	W5514	5601	22		W	21-33-11	YC060-YC064
SP00586		IFSS-168/ /					ALL
	W1180	2002R	20		9	27-81-11	ALL
	W1180	J-R			9	27-81-11	ALL
SP00588		IFSS-164/ /					ALL
	W1180	2001R	20		9	27-81-11	ALL
	W1180	I-R			9	27-81-11	ALL
SP00590		IFSS-149/ /					ALL
	W1180	2003R	20		9	27-81-11	ALL

SPLICE LIST

D280A108

91-21-31

Section SP00500

Page 4

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00590		IFSS-149/ / (continued)					ALL
	W1180	K-R			9	27-81-11	ALL
SP00592		IFSS-149/ /					ALL
	W1180	2004R	20		9	27-81-11	ALL
	W1180	L-R			9	27-81-11	ALL
SP00593		280/287/R006					YL951-YR328
	W2218	0202	22		9	23-42-11	YL951-YR328
	W2508	1008	22		9	23-42-11	YL951-YR328
	W2508	1010	22		9	23-42-11	YL951-YR328
SP00595		333/308/L019					YL951-YR328
	W2218	0002	22		9	23-42-11	YL951-YN260
	W2218	0006	22		9	23-43-11	YL951-YR328
	W2218	0010	22		9	23-43-11	YL951-YR328
	W2218	0011	22		9	23-42-11	YL951-YR328
	W2218	0201	22		9	23-42-11	YL951-YR328
	W3058	0197	22		9	23-42-11	YR316-YR328
	W3307	0067	22		9	23-42-11	YL951-YR315

SPLICE LIST

D280A108

91-21-31

Section SP00500

Page 5 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00606		228/270/L020					YC051-YD151
SP00606		233/265/L025					YD152-YR328
	W2102	5505	20		S	33-17-11	ALL
	W2102	B-BP			S	33-17-11	ALL
SP00608		227/268/R019					ALL
	W2204	5517	20		S	33-17-11	ALL
	W2204	B-BP			S	33-17-11	ALL
SP00613		333/308/L019					YL951-YR328
	W2508	1011	22		9	23-42-11	YL951-YR328
	W3058	0047	22		9	23-42-11	YL951-YR328
SP00617		333/308/L019					YL951-YR328
	W2508	1012	22		9	23-42-11	YL951-YR328
	W3058	0048	22		9	23-42-11	YL951-YR328
SP00619		430/300/R020					YL951-YL954, YN231-YN260
	W3309	0001	22		9	46-11-51	YL951-YL954, YN231-YN235
	W6170	6003	22		9	46-11-51	YL951-YL954, YN231-YN235
SP00621		333/308/L019					YL951-YR328
	W2218	0203	22		9	23-42-11	YL951-YR328
	W3058	0049	22		9	23-42-11	YL951-YR328
SP00634		727+17/202/L053					ALL
	W5124	0569	18		S	29-25-11	ALL
	W6124	0576	20		S	27-53-11	ALL
	W6124	0577	20		S	27-53-11	ALL
SP00642		727A+11/297/L023					YC051-YL999, YR301-YR328
	W3142	0074	20		S	33-51-22	YC051-YD157
	W3142	0245	16		S	33-51-22	YD158-YL999
	W4142	0210	20		S	33-51-22	YC051-YD157
	W4142	0230	16		S	33-51-22	YD158-YL999
SP00656		239/197/L01					ALL
	W5170	6011	20		S	28-21-11	ALL
	W5506	6029	20		S	28-21-11	YC051-YD158, YL951-YL968, YN231-YN236, YN501-YR328
	W5506	6030	20		S	28-21-11	YC051-YD158, YL951-YL968, YN231-YN236, YN501-YR328

SPLICE LIST

D280A108

91-21-31

Section SP00600

Page 1

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00656	W5506	239/197/L01 (continued)					ALL
		6082	20		S	28-21-11	YC051-YD158, YL951-YL968, YN231-YN236, YN501-YR328
SP00665		220/207/L045					ALL
SP00667		220/208/L045					ALL
SP00681		220/208/L045					ALL
SP00683		220/208/L045					ALL
SP00685		240/260/L040					ALL

SPLICE LIST

D280A108

91-21-31

Section SP00600

Page 2 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00702		636/220/L070					ALL
	W3142	5513	20		9	21-42-11	YN231-YN501
	W3142	5573	20		9	21-42-11	YC051-YL999, YR301-YR328
	W3142	C-A			9	21-42-11	ALL
SP00704		636/220/L070					ALL
	W3142	5514	20		9	21-42-11	YN231-YN501
	W3142	5574	20		9	21-42-11	YC051-YL999, YR301-YR328
	W3142	C-B			9	21-42-11	ALL
SP00706		TBD/ /					ALL
SP00708		599/220/R070					YC051-YL999, YR301-YR328
	W4142	5544	20		9	21-42-11	YC051-YL999, YR301-YR328
	W4142	J-A			9	21-42-11	YC051-YL999, YR301-YR328
SP00710		599/220/R070					YC051-YL999, YR301-YR328
	W4142	5545	20		9	21-42-11	YC051-YL999, YR301-YR328
	W4142	J-B			9	21-42-11	YC051-YL999, YR301-YR328
SP00724		637/220/R070					ALL
	W4142	5513	20		9	21-42-11	ALL
	W4142	C-A			9	21-42-11	ALL
SP00726		637/220/R070					ALL
	W4142	5514	20		9	21-42-11	ALL
	W4142	C-B			9	21-42-11	ALL
SP00728		//					ALL
SP00730		//					ALL
SP00779		265/198/R040					YN236-YR328
	W5257	0001	22		S	31-35-03	YN236-YR328
	W6510	0012	22		S	31-35-03	YN236-YR328
SP00795		236/ /					YC060-YC064
	W5156	0696	22		W	31-53-11	YC060-YC064
	W5514	5602	22		W	31-53-11	YC060-YC064

SPLICE LIST

D280A108

91-21-31

Section SP00700

Page 1 End

Nov 12/2012

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00802		639/257/L067					ALL
	W3142	0418	20		9	52-71-13	YC051-YL999, YR301-YR328
	W3142	0462	20		9	52-71-13	YN231-YN501
	W3142	F-A			9	52-71-13	ALL
SP00804		635/258/L067					ALL
	W3142	0463	20		9	52-71-13	ALL
	W3142	F-B			9	52-71-13	ALL
SP00806		634/259/L068					ALL
	W3142	0464	20		9	52-71-13	ALL
	W3142	H-A			9	52-71-13	ALL
SP00808		634/259/L068					ALL
	W3142	0465	20		9	52-71-13	ALL
	W3142	H-B			9	52-71-13	ALL
SP00810		616/257/L067					ALL
	W3142	0466	20		9	52-71-13	ALL
	W3142	I-A			9	52-71-13	ALL
SP00812		616/257/L067					ALL
	W3142	0467	20		9	52-71-13	ALL
	W3142	I-B			9	52-71-13	ALL
SP00814		639/257/L067					ALL
	W3142	0460	20		9	52-71-13	ALL
	W3142	G-A			9	52-71-13	ALL
SP00816		639/257/L067					ALL
	W3142	0461	20		9	52-71-13	ALL
	W3142	G-B			9	52-71-13	ALL
SP00817		334/291/L20					YN501-YR328
	W3058	0098	22		S	23-42-14	YN501-YR328
	W3058	0166	22		S	23-42-15	YN501-YR328
	W3307	0083	22		S	23-42-14	YN501-YR328
SP00818		595/256/L068					YC051-YL999, YR301-YR328
	W3142	0419	20		9	52-71-13	YC051-YL999, YR301-YR328

SPLICE LIST
D280A108

91-21-31
Section SP00800
Page 1
Nov 12/2012

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00818		595/256/L068 (continued)					YC051-YL999, YR301-YR328
	W3142	N-A			9	52-71-13	YC051-YL999, YR301-YR328
SP00820		595/256/L068					YC051-YL999, YR301-YR328
	W3142	0420	20		9	52-71-13	YC051-YL999, YR301-YR328
	W3142	N-B			9	52-71-13	YC051-YL999, YR301-YR328
SP00822		595/256/L068					YC051-YL999, YR301-YR328
	W3142	0434	20		9	52-71-13	YC051-YL999, YR301-YR328
	W3142	R-A			9	52-71-13	YC051-YL999, YR301-YR328
SP00823		338/291/L019					YN501-YR328
	W3477	0001	20		9	44-21-10	YN501-YR328
	W6212	0003	20		9	44-21-10	YN501-YR328
SP00824		595/256/L068					YC051-YL999, YR301-YR328
	W3142	0435	20		9	52-71-13	YC051-YL999, YR301-YR328
	W3142	R-B			9	52-71-13	YC051-YL999, YR301-YR328
SP00825		338/291/L019					YN501-YR328
	W3477	0002	20		9	44-21-10	YN501-YR328
	W6212	0010	20		9	44-21-10	YN501-YR328
SP00826		575/258/L067					YC051-YL999, YR301-YR328
	W3142	0436	20		9	52-71-13	YC051-YL999, YR301-YR328
	W3142	P-A			9	52-71-13	YC051-YL999, YR301-YR328
SP00827		862/296/R023					YN501-YR328
	W3309	0005	24		9	23-27-35	YN501-YR317
	W3309	2505R	24		V	23-27-35	YR318-YR328
	W3309	2505Z				23-27-35	YR318-YR328
	W5431	0010	24		9	23-27-35	YN501-YR317
	W5431	2008R	24		V	23-27-35	YR318-YR328
	W5431	2008Z				23-27-35	YR318-YR328
SP00828		575/258/L067					YC051-YL999, YR301-YR328
	W3142	0437	20		9	52-71-13	YC051-YL999, YR301-YR328
	W3142	P-B			9	52-71-13	YC051-YL999, YR301-YR328

SPLICE LIST

D280A108

91-21-31

Section SP00800

Page 2

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00829		862/296/R023					YN501-YR328
	W3309	0006	24		9	23-27-35	YN501-YR317
	W3309	2505B	24		V	23-27-35	YR318-YR328
	W5431	0011	24		9	23-27-35	YN501-YR317
	W5431	2008B	24		V	23-27-35	YR318-YR328
SP00830		604/258/L067					YC051-YL999, YR301-YR328
	W3142	0438	20		9	52-71-13	YC051-YL999, YR301-YR328
	W3142	Q-A			9	52-71-13	YC051-YL999, YR301-YR328
SP00831		334/291/L020					YN501-YR328
	W3058	0176	22		S	23-42-14	YN501-YR328
	W3058	0187	22		S	23-42-15	YN501-YR328
	W3058	0191	22		S	23-42-14	YN501-YR328
	W5160	0140	22		S	23-42-14	YN501-YR328
SP00832		604/258/L067					YC051-YL999, YR301-YR328
	W3142	0439	20		9	52-71-13	YC051-YL999, YR301-YR328
	W3142	Q-B			9	52-71-13	YC051-YL999, YR301-YR328
SP00839		333/308/L019					YN501
SP00843		//					YN501-YR301
	W0041	2504R	22		S	31-32-15	YN501-YR301
	W0041	2533R	22		S	31-32-15	YN501-YR301
	W0054	2011R	24		S	23-42-14	YN501-YR301
SP00845		//					YN501-YR301
	W0041	2504B	22		S	31-32-15	YN501-YR301
	W0041	2533B	22		S	31-32-15	YN501-YR301
	W0054	2011B	24		S	23-42-14	YN501-YR301
SP00847		//					YN501-YR301
	W0041	2504Z			S	31-32-15	YN501-YR301
	W0041	2533Z			S	31-32-15	YN501-YR301
	W0054	2011Z			S	23-42-14	YN501-YR301
SP00849		//					YN501

SPLICE LIST
D280A108

91-21-31
Section SP00800
Page 3
Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00851		//					YN501
SP00853		//					YN501
SP00855		//					YN501
SP00857		//					YN501
SP00859		//					YN501
SP00861		//					YN501
I SP00867		336/290/L003					YL963-YL999, YN236-YR328
I	W3004	0004	24		W	23-71-01	YL963-YL999, YN236-YR328
I	W3329	0013	24		W	23-71-01	YL963-YL999, YN236-YR328
SP00869		333/308/L019					YN501-YR315
	W3058	0197	22		9	23-42-11	YN501-YR315
	W3307	0067	22		9	23-42-11	YN501-YR315
I SP00875		280/285/R001					YL968-YL999, YN236-YR328
I	W2212	5555	22		9	30-31-12	YL968-YL999, YN236-YR328
I	W3381	0023	22		9	30-31-12	YL968-YL999, YN236-YR328
I SP00888		OFSS 126/ /					ALL
I	W1664	1019	20		9	28-44-11	YC051-YD158, YL951-YR328
I	W1664	B-B			9	28-44-11	YC051-YD158, YL951-YR328
I SP00889		E003-01/ /					ALL
I	W0311	0006	22		W	30-31-12	YL968-YL999, YN236-YR328
I	W0311	0008	22		W	30-31-12	YL968-YL999, YN236-YR328
I	W0313	0004	22		W	30-31-12	YL968-YL999, YN236-YR328
I	W0313	0005	22		W	30-31-12	YL968-YL999, YN236-YR328
I SP00891		E003-01/ /					ALL
I	W0311	0007	22		W	30-31-12	YL968-YL999, YN236-YR328
I	W0311	0009	22		W	30-31-12	YL968-YL999, YN236-YR328
I	W0313	0003	22		W	30-31-12	YL968-YL999, YN236-YR328
I	W0313	0006	22		W	30-31-12	YL968-YL999, YN236-YR328

SPLICE LIST

D280A108

91-21-31

Section SP00800

Page 4

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00894		P008-00/ /					YC051-YC052
SP00897		330/286/L019					YN501-YR328
	W2112	0062	22		S	33-22-11	YN501-YR328
	W5142	0093	22		S	33-22-11	YN501-YR328
SP00899		330/286/L019					YN501-YR328
	W2112	0063	22		S	33-22-11	YN501-YR328
	W5142	0094	22		S	33-22-11	YN501-YR328

SPLICE LIST

D280A108

91-21-31

Section SP00800

Page 5 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00928		OFSS 375/ /					ALL
	W1664	1012	20		9	28-44-11	YC051-YD158, YL951-YR328
	W1664	1013	18		9	28-44-11	YC051-YD158, YL951-YR328
	W1664	A-B			9	28-44-11	YC051-YD158, YL951-YR328
	W1664	A-C			9	28-44-11	YC051-YD158, YL951-YR328
SP00968		257/194/L008					ALL
	W5160	6023	20		S	78-34-21	YC051-YD158, YL951-YR328
	W5160	6026	20		S	78-34-21	YC051-YD158, YL951-YR328
	W6506	6015	20		S	78-34-21	ALL
	W6510	6031	20		S	78-34-21	YC051-YD158, YL951-YR328
SP00998		OFSS 126/ /					ALL
	W1664	1026	20		9	28-44-11	YC051-YD158, YL951-YR328
	W1664	B-A			9	28-44-11	YC051-YD158, YL951-YR328

SPLICE LIST

D280A108

91-21-31

Section SP00900

Page 1 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
I SP01062		907/198/R054					YL951-YR328
I SP01064		907/198/R054					YL951-YR328
I SP01066		907/198/R054					YL951-YR328
I SP01068		907/198/R054					YL951-YR328
I SP01080		266/204/L047					ALL
I	W2653	0014	10		9	30-42-11	YC062-YR328
I	W5506	0019	10		9	30-42-11	YC062-YD158, YL951-YL968, YN231-YN236, YN501-YR328
I SP01082		235/208/R038					ALL
I	W2208	5502	18		9	30-42-11	YC062-YC063
I	W2208	5504	10		9	30-42-11	YC064-YD158, YL951-YR328
I	W5506	0019	10		9	30-42-11	YC062-YD158, YL951-YL968, YN231-YN236, YN501-YR328
I SP01084		268/204/L048					ALL
I	W2108	5502	18		9	30-42-11	YC062-YC063
I	W2108	5504	10		9	30-42-11	YC064-YR328
I	W2175	0026	10		9	30-42-11	YC062-YR328

SPLICE LIST

D280A108

91-21-31

Section SP01000

Page 1 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01118		305/266/L050					ALL
	W5110	2419R	20		9	52-71-11	ALL
	W5110	A-A			9	52-71-11	ALL
SP01120		305/266/L050					ALL
	W5110	0101	20		9	52-71-11	ALL
	W5110	A-C			9	52-71-11	ALL
SP01122		305/266/L050					ALL
	W5110	2419B	20		9	52-71-11	ALL
	W5110	A-B			9	52-71-11	ALL
SP01124		993/265/L055					ALL
	W6248	2409R	20		9	52-71-11	YC051-YN236, YN501-YR328
	W6248	B-A			9	52-71-11	YC051-YN236, YN501-YR328
SP01126		993/265/L055					ALL
	W6248	0102	20		9	52-71-11	YC051-YN236, YN501-YR328
	W6248	B-C			9	52-71-11	YC051-YN236, YN501-YR328
SP01128		993/265/L055					ALL
	W6248	2409B	20		9	52-71-11	YC051-YN236, YN501-YR328
	W6248	B-B			9	52-71-11	YC051-YN236, YN501-YR328
SP01144		997/261/R056					ALL
	W6248	2444R	20		9	52-71-11	YC051-YN236, YN501-YR328
	W6248	D-A			9	52-71-11	YC051-YN236, YN501-YR328
SP01146		997/261/R056					ALL
	W6248	0104	20		9	52-71-11	YC051-YN236, YN501-YR328
	W6248	D-C			9	52-71-11	YC051-YN236, YN501-YR328
SP01148		997/261/R056					ALL
	W6248	2444B	20		9	52-71-11	YC051-YN236, YN501-YR328
	W6248	D-B			9	52-71-11	YC051-YN236, YN501-YR328
SP01158		332/267/R055					ALL
	W6412	2401R	20		9	52-71-11	YC051-YN236, YN501-YR323, YR325-YR328
	W6412	C-A			9	52-71-11	YC051-YN236, YN501-YR323, YR325-YR328

SPLICE LIST

D280A108

91-21-31

Section SP01100

Page 1

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
I SP01160		332/267/R055					ALL
I	W6412	0005	20		9	52-71-11	YC051-YN236, YN501-YR323, YR325-YR328
I	W6412	C-C			9	52-71-11	YC051-YN236, YN501-YR323, YR325-YR328
I SP01162		332/267/R055					ALL
I	W6412	2401B	20		9	52-71-11	YC051-YN236, YN501-YR323, YR325-YR328
I	W6412	C-B			9	52-71-11	YC051-YN236, YN501-YR323, YR325-YR328

SPLICE LIST

D280A108

91-21-31

Section SP01100

Page 2 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01246		785/167/R044					YL953-YL999, YN234-YR328
	W6248	0046	20		S	52-71-12	YL953-YL999, YN234-YN236, YN501-YR328
	W6248	A-A			S	52-71-12	YL953-YL999, YN234-YN236, YN501-YR328
SP01248		785/168/R044					YL953-YL999, YN234-YR328
	W6248	0146	20		S	52-71-12	YL953-YL999, YN234-YN236, YN501-YR328
	W6248	A-B			S	52-71-12	YL953-YL999, YN234-YN236, YN501-YR328
SP01256		436/164/R041					YL953-YL999, YN234-YR328
	W5248	0056	20		S	52-71-12	YL953-YL999, YN234-YR328
	W5248	A-A			S	52-71-12	YL953-YL999, YN234-YR328
SP01258		436/164/R041					YL953-YL999, YN234-YR328
	W5248	0156	20		S	52-71-12	YL953-YL999, YN234-YR328
	W5248	A-B			S	52-71-12	YL953-YL999, YN234-YR328

SPLICE LIST

D280A108

91-21-31

Section SP01200

Page 1 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01502		257/194/L007					ALL
	W5160	0701	22		S	32-42-11	YC051-YD158, YL951-YR328
	W5160	0702	22		S	32-42-11	YC051-YD158, YL951-YR328
	W5506	0511	24		S	32-42-11	YC051-YD158, YL951-YL968, YN231-YN236, YN501-YR328
SP01504		257/194/L007					ALL
	W5160	0704	22		S	32-42-11	YC051-YD158, YL951-YR328
	W5160	0705	22		S	32-42-11	YC051-YD158, YL951-YR328
	W5506	0513	24		S	32-42-11	YC051-YD158, YL951-YL968, YN231-YN236, YN501-YR328
SP01523		1206/336/R002					YD158-YR328
	W7057	0018	22		9	23-11-11	YD158-YR328
	W7061	0018	22		9	23-11-11	YD158-YR328
SP01525		1206/336/R002					YD158-YR328
	W7057	0017	22		9	23-11-11	YD158-YR328
	W7061	0017	22		9	23-11-11	YD158-YR328

SPLICE LIST

D280A108

91-21-31

Section SP01500

Page 1 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01732		OFSS 589/ /					ALL
	W1664	1024	20		9	28-44-11	YC051-YD158, YL951-YR328
	W1664	A-J			9	28-44-11	YC051-YD158, YL951-YR328
SP01734		OFSS 589/ /					ALL
	W1664	1018	20		9	28-44-11	YC051-YD158, YL951-YR328
	W1664	A-K			9	28-44-11	YC051-YD158, YL951-YR328

For training purposes only!

SPLICE LIST

D280A108

91-21-31

Section SP01700

Page 1 End

Nov 12/2012

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01802		625/257/R067					ALL
	W4142	0438	20		9	52-71-14	YC051-YL999, YR301-YR328
	W4142	0462	20		9	52-71-14	YN231-YN501
	W4142	F-A			9	52-71-14	ALL
SP01804		625/257/R067					ALL
	W4142	0463	20		9	52-71-14	ALL
	W4142	F-B			9	52-71-14	ALL
SP01806		622/261/R066					ALL
	W4142	0464	20		9	52-71-14	ALL
	W4142	H-A			9	52-71-14	ALL
SP01808		640/257/R067					ALL
	W4142	0465	20		9	52-71-14	ALL
	W4142	H-B			9	52-71-14	ALL
SP01810		616/257/R067					ALL
	W4142	0466	20		9	52-71-14	ALL
	W4142	I-A			9	52-71-14	ALL
SP01812		616/257/R067					ALL
	W4142	0467	20		9	52-71-14	ALL
	W4142	I-B			9	52-71-14	ALL
SP01814		640/259/R067					ALL
	W4142	0460	20		9	52-71-14	ALL
	W4142	G-A			9	52-71-14	ALL
SP01816		643/257/R067					ALL
	W4142	0461	20		9	52-71-14	ALL
	W4142	G-B			9	52-71-14	ALL
SP01818		583/256/R068					YC051-YL999, YR301-YR328
	W4142	0436	20		9	52-71-14	YC051-YL999, YR301-YR328
	W4142	N-A			9	52-71-14	YC051-YL999, YR301-YR328
SP01820		587/254/R068					YC051-YL999, YR301-YR328
	W4142	0435	20		9	52-71-14	YC051-YL999, YR301-YR328
	W4142	N-B			9	52-71-14	YC051-YL999, YR301-YR328

SPLICE LIST
D280A108

91-21-31
Section SP01800
Page 1
Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01822		583/256/R068					YC051-YL999, YR301-YR328
	W4142	0437	20		9	52-71-14	YC051-YL999, YR301-YR328
	W4142	R-A			9	52-71-14	YC051-YL999, YR301-YR328
SP01824		583/256/R068					YC051-YL999, YR301-YR328
	W4142	0439	20		9	52-71-14	YC051-YL999, YR301-YR328
	W4142	R-B			9	52-71-14	YC051-YL999, YR301-YR328
SP01826		578/259/R067					YC051-YL999, YR301-YR328
	W4142	0440	20		9	52-71-14	YC051-YL999, YR301-YR328
	W4142	P-A			9	52-71-14	YC051-YL999, YR301-YR328
SP01828		578/259/R067					YC051-YL999, YR301-YR328
	W4142	0441	20		9	52-71-14	YC051-YL999, YR301-YR328
	W4142	P-B			9	52-71-14	YC051-YL999, YR301-YR328
SP01830		601/259/R067					YC051-YL999, YR301-YR328
	W4142	0442	20		9	52-71-14	YC051-YL999, YR301-YR328
	W4142	Q-A			9	52-71-14	YC051-YL999, YR301-YR328
SP01832		601/259/R067					YC051-YL999, YR301-YR328
	W4142	0443	20		9	52-71-14	YC051-YL999, YR301-YR328
	W4142	Q-B			9	52-71-14	YC051-YL999, YR301-YR328

SPLICE LIST

D280A108

91-21-31

Section SP01800

Page 2 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL	GA	CO	Type	Diagram	Effectivity
		Wire No.					
I SP01948		OFSS-712/ /					ALL
I	W1188	2005R	20		9	27-81-12	ALL
I	W1188	A-R			9	27-81-12	ALL

For training purposes only!

SPLICE LIST

D280A108

91-21-31

Section SP01900

Page 1 End

Nov 12/2012



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02002		368/176/L048					ALL
	W5030	5506	20		S	21-27-31	ALL
	W5122	5501	22		S	21-27-31	ALL
SP02004		371/174/R043					ALL
	W6242	5509	24		S	21-27-31	ALL
	W6430	5506	20		S	21-27-31	ALL
SP02085		237/208/L036					ALL
	W2205	0014	20		S	34-21-11	YC051-YD157
	W2205	0014	20		S	SPARE	YD158, YL951-YR328
	W2651	0010	20		S	34-21-11	YC051-YD157
	W2651	0010	20		S	SPARE	YD158-YR328

SPICE LIST

D280A108

91-21-31

Section SP02000

Page 1 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02135		237/208/L036					ALL
	W2363	1064	22		S	22-14-11	ALL
	W2363	1064Z				22-14-11	ALL
	W5514	1001	22		S	22-14-11	YC051-YD158, YL951-YR328
	W5514	1001Z				22-14-11	YC051-YD158, YL951-YR328
SP02138		237/208/L036					ALL
	W2030	5505	16		S	33-11-11	ALL
	W2102	5509	20		S	33-11-11	ALL
SP02140		236/210/R038					ALL
	W2204	5512	20		S	33-11-21	ALL
	W2383	0033	16		S	33-11-21	ALL
SP02141		231/226/R038					YD158-YD170
	W2383	0035	20		S	SPARE	YD158-YD170
SP02185		237/208/L036					ALL
	W2205	0054	22		S	34-22-11	YC051-YD158, YL951-YR328
	W2651	0008	22		S	34-22-11	ALL
SP02186		237/208/L036					ALL
	W2205	0007	22		S	34-24-11	YC051-YD157
	W2205	0007	22		S	SPARE	YD158, YL951-YR328
	W2651	0009	22		S	34-24-11	YC051-YD157
	W2651	0009	22		S	SPARE	YD158-YR328
SP02189		237/208/L036					YC051-YD170
SP02191		237/208/L036					YN231-YN501
	W2651	0031	22		S	SPARE	YN231-YN501
SP02195		237/208/R036					YD158-YR328
	W2205	0038	22		S	34-24-15	YD158
	W2205	0038	20		S	34-24-15	YL951-YR328
	W3319	0034	22		S	34-24-15	YD158
	W3319	0034	20		S	34-24-15	YL951-YR328

SPLICE LIST

D280A108

91-21-31

Section SP02100

Page 1 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02205		237/208/R036					ALL
	W2030	5508	16		S	33-11-32	ALL
	W2205	0001	20		S	33-11-32	YC051-YD157
	W2205	0003	20		S	33-11-32	YC051-YD158, YL951-YR328
	W2205	0010	20		S	33-11-32	YD158, YL951-YR328
	W2205	0015	20		S	33-11-32	YC051-YD157

For training purposes only!

SPLICE LIST

D280A108

91-21-31

Section SP02200

Page 1 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02846		/ /					YC051-YL999, YR301-YR328
SP02876		OFSS-712/ /					ALL
	W1188	2005B	20		9	27-81-12	ALL
	W1188	A-B			9	27-81-12	ALL
SP02884		OFSS-662/ /					ALL
	W1188	2006R	20		9	27-81-12	ALL
	W1188	B-R			9	27-81-12	ALL
SP02886		OFSS-662/ /					ALL
	W1188	2006B	20		9	27-81-12	ALL
	W1188	B-B			9	27-81-12	ALL

SPLICE LIST
D280A108

91-21-31
Section SP02800
Page 1 End
Nov 12/2012



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02936		OFSS-581/ /					ALL
	W1188	2007R	20		9	27-81-12	ALL
	W1188	C-R			9	27-81-12	ALL
SP02938		OFSS-581/ /					ALL
	W1188	2007B	20		9	27-81-12	ALL
	W1188	C-B			9	27-81-12	ALL
SP02940		OFSS-534/ /					ALL
	W1188	2008R	20		9	27-81-12	ALL
	W1188	D-R			9	27-81-12	ALL
SP02942		OFSS-534/ /					ALL
	W1188	2008B	20		9	27-81-12	ALL
	W1188	D-B			9	27-81-12	ALL
SP02944		OFSS-459/ /					ALL
	W1188	2009R	20		9	27-81-12	ALL
	W1188	E-R			9	27-81-12	ALL
SP02990		333/308/L019					ALL
	W3058	0371	22		S	33-27-11	YC051-YD158, YL951-YR328
	W3150	0914	22		S	33-27-11	ALL
	W3150	0923	22		S	33-27-21	ALL

SPlice LIST

D280A108

91-21-31

Section SP02900

Page 1 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03060		856/296/L024					ALL
	W3058	0060	20		S	38-32-13	YC051-YD158, YL951-YR328
	W3058	0208	20		S	38-32-13	YC051-YD158, YL951-YN260
	W3058	0227	20		S	38-32-13	YN501-YR328
	W3144	0020	20		S	38-32-13	ALL
SP03076		* / /					YC051-YD154
	W3058	0006	22		S	52-51-11	YC051-YD154
	W3058	A-A			S	52-51-11	YC051-YD154
SP03078		280/248/R010					ALL
	W3058	0007	20		S	52-51-11	YC051-YD154
	W3058	A-B			S	52-51-11	YC051-YD154
SP03097		238/196/R002					ALL
	W5369	0106	22		S	22-31-51	ALL
	W5457	0001	22		S	22-31-51	ALL
	W5457	0106	22		S	22-31-51	ALL

SPLICE LIST

D280A108

91-21-31

Section SP03000

Page 1 End

Nov 12/2012



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03101		238/196/R002					ALL
	W5369	0108	22		S	22-31-51	ALL
	W5457	0108	22		S	22-31-51	ALL
SP03103		E003-01/ /					YD158-YR328
	W0311	0221	24		W	31-62-41	YD158-YR328
	W0313	0571	24		W	31-62-41	YD158-YR328
	W0313	0572	24		W	31-62-41	YD158-YR328
SP03104		E003-01/ /					YL951-YR328
	W0311	0178	24		W	31-62-42	YL951-YR328
	W0313	0631	24		W	31-62-42	YL951-YR328
	W0313	0632	24		W	31-62-42	YL951-YR328

SPLICE LIST

D280A108

91-21-31

Section SP03100

Page 1 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
------------	--------	-------------------------------	----	----	------	---------	-------------

I	SP03210	//					ALL
---	---------	----	--	--	--	--	-----

For training purposes only!

SPLICE LIST

D280A108

91-21-31

Section SP03200

Page 1 End

Nov 12/2012



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
I SP03362		OFSS-459/ /					ALL
I	W1188	2009B	20		9	27-81-12	ALL
I	W1188	E-B			9	27-81-12	ALL
I SP03380		OFSS-415/ /					ALL
I	W1188	2010R	20		9	27-81-12	ALL
I	W1188	F-R			9	27-81-12	ALL

For training purposes only!

SPlice LIST

D280A108

91-21-31

Section SP03300

Page 1 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03420		//					ALL
SP03422		OFSS-415/ /					ALL
	W1188	2010B	20		9	27-81-12	ALL
	W1188	F-B			9	27-81-12	ALL
SP03428		OFSS-341/ /					ALL
	W1188	2011R	20		9	27-81-12	ALL
	W1188	G-R			9	27-81-12	ALL
SP03430		OFSS-341/ /					ALL
	W1188	2011B	20		9	27-81-12	ALL
	W1188	G-B			9	27-81-12	ALL
SP03432		OFSS-300/ /					ALL
	W1188	2012R	20		9	27-81-12	ALL
	W1188	H-R			9	27-81-12	ALL
SP03436		OFSS-300/ /					ALL
	W1188	2012B	20		9	27-81-12	ALL
	W1188	H-B			9	27-81-12	ALL
SP03438		OFSS 341/ /					ALL
	W1288	2005R	20		9	27-81-22	ALL
	W1288	A-R			9	27-81-22	ALL
SP03440		OFSS 341/ /					ALL
	W1288	2005B	20		9	27-81-22	ALL
	W1288	A-B			9	27-81-22	ALL
SP03442		OFSS 300/ /					ALL
	W1288	2006R	20		9	27-81-22	ALL
	W1288	B-R			9	27-81-22	ALL
SP03446		OFSS 300/ /					ALL
	W1288	2006B	20		9	27-81-22	ALL
	W1288	B-B			9	27-81-22	ALL
SP03448		OFSS 459/ /					ALL
	W1288	2007R	20		9	27-81-22	ALL

SPLICE LIST

D280A108

91-21-31

Section SP03400

Page 1

Nov 12/2012

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03448		OFSS 459/ / (continued)					ALL
	W1288	C-R			9	27-81-22	ALL
SP03450		OFSS 459/ /					ALL
	W1288	2007B	20		9	27-81-22	ALL
	W1288	C-B			9	27-81-22	ALL
SP03454		OFSS 415/ /					ALL
	W1288	2008R	20		9	27-81-22	ALL
	W1288	D-R			9	27-81-22	ALL
SP03456		OFSS 415/ /					ALL
	W1288	2008B	20		9	27-81-22	ALL
	W1288	D-B			9	27-81-22	ALL
SP03458		OFSS 581/ /					ALL
	W1288	2009R	20		9	27-81-22	ALL
	W1288	E-R			9	27-81-22	ALL
SP03460		OFSS 581/ /					ALL
	W1288	2009B	20		9	27-81-22	ALL
	W1288	E-B			9	27-81-22	ALL
SP03462		OFSS 534/ /					ALL
	W1288	2010R	20		9	27-81-22	ALL
	W1288	F-R			9	27-81-22	ALL
SP03466		OFSS 534/ /					ALL
	W1288	2010B	20		9	27-81-22	ALL
	W1288	F-B			9	27-81-22	ALL
SP03468		OFSS 712/ /					ALL
	W1288	2011R	20		9	27-81-22	ALL
	W1288	G-R			9	27-81-22	ALL
SP03470		OFSS 712/ /					ALL
	W1288	2011B	20		9	27-81-22	ALL
	W1288	G-B			9	27-81-22	ALL

SPLICE LIST

D280A108

91-21-31

Section SP03400

Page 2

Nov 12/2012

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03472		OFSS 662/ /					ALL
	W1288	2012R	20		9	27-81-22	ALL
	W1288	H-R			9	27-81-22	ALL
SP03474		OFSS 662/ /					ALL
	W1288	2012B	20		9	27-81-22	ALL
	W1288	H-B			9	27-81-22	ALL
SP03476		OFSS-589/ /					ALL
	W1662	2001R	20		9	28-44-11	YC051-YD158, YL951-YR328
	W1662	M-R			9	28-44-11	YC051-YD158, YL951-YR328
SP03478		OFSS-589/ /					ALL
	W1662	2001B	20		9	28-44-11	YC051-YD158, YL951-YR328
	W1662	M-B			9	28-44-11	YC051-YD158, YL951-YR328
SP03480		333/308/L019					ALL
	W3058	0363	20		S	33-51-12	YC051-YD157, YN231-YN260
	W3058	0363	16		S	33-51-12	YD158, YL951-YL999
	W3058	0363	20		9	33-51-12	YN501-YR328
	W4142	0061	16		S	33-51-12	YD158-YL999
	W4142	0113	20		S	33-51-12	YC051-YD157, YN231-YN260
	W4142	0113	20		9	33-51-12	YN501-YR328
SP03483		265/184/L065					ALL
SP03484		937/317/L013					ALL
	W3058	0463	20		S	33-51-14	YC051-YD158, YL951-YR328
	W3142	0413	20		S	33-51-14	YC051-YL999, YR301-YR328
	W4142	0413	20		S	33-51-14	YN231-YN501
SP03485		250/195/R040					ALL
SP03490		937/298/L013					ALL
	W3058	0470	22		S	33-27-22	YC051-YD158, YL951-YR328
	W3144	0083	22		S	33-27-22	ALL
SP03492		937/300/L013					ALL
	W3058	0469	22		S	33-27-22	YC051-YD158, YL951-YR328
	W3144	0317	22		S	33-27-22	ALL

SPLICE LIST

D280A108

91-21-31

Section SP03400

Page 3

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03492		937/300/L013 (continued)					ALL
	W3144	0367	22		S	33-27-32	YC051-YL999, YR301-YR328
SP03496		333/290/L019					ALL
SP03498		333/308/L019					ALL
	W3058	0372	22		S	33-27-11	YC051-YD158, YL951-YR328
	W3144	0117	22		S	33-27-11	ALL

SPLICE LIST

D280A108

91-21-31

Section SP03400

Page 4 End

Nov 12/2012

BOEING PROPRIETARY - Copyright © Unpublished Work - See title page for details



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03504		328/291/L001					YC051-YN260
	W0050	0010	20		S	33-29-11	YC051-YN260
	W0050	A-C			S	33-29-11	YC051-YN260
	W0050	A-H			S	33-29-11	YC051-YN260
SP03506		328/291/L001					YC051-YN260
	W0050	0011	20		S	33-29-11	YC051-YN260
	W0050	A-D			S	33-29-11	YC051-YN260
	W0050	A-G			S	33-29-11	YC051-YN260
SP03508		977/293/L014					YC051-YN260
	W0052	0010	20		S	33-29-11	YC051-YN260
	W0052	A-C			S	33-29-11	YC051-YN260
	W0052	A-H			S	33-29-11	YC051-YN260
SP03512		977/293/R014					YC051-YN260
	W0052	0011	20		S	33-29-11	YC051-YN260
	W0052	A-D			S	33-29-11	YC051-YN260
	W0052	A-G			S	33-29-11	YC051-YN260
SP03522		937/317/L013					ALL
	W3058	0069	22		S	33-26-11	YN501-YR328
	W3058	0422	22		S	33-26-11	YC051-YD158, YL951-YN260
	W3142	0475	22		S	33-26-11	ALL
	W4142	0475	22		S	33-26-11	ALL

SPLICE LIST
D280A108

91-21-31
Section SP03500
Page 1 End
Nov 12/2012



	Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
I	SP03707		265/184/L065					ALL
I	SP03709		250/195/R040					ALL
I	SP03731		365/200/L030					ALL
I	SP03745		200/211/L008					ALL
I	SP03747		200/211/L008					ALL
I	SP03749		200/211/L008					ALL

SPLICE LIST

D280A108

91-21-31

Section SP03700

Page 1 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Station / WL / BL		GA	CO	Type	Diagram	Effectivity
	Bundle	Wire No.					
I SP03891		311/168/L042					ALL
	W2103	0010	22		S	23-31-06	YC051-YC052, YD158, YL951-YN260
	W3307	0012	22		S	23-31-06	YC051-YC052, YD158-YN260

For training purposes only!

SPLICE LIST

D280A108

91-21-31

Section SP03800

Page 1 End

Nov 12/2012



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
I SP04010		998/300/L005					ALL
I	W3158	0206	18		S	33-35-11	ALL
I	W5726	0011	18		S	33-35-11	ALL
I SP04012		//					ALL
I SP04014		//					ALL
I SP04016		*/**					ALL

SPLICE LIST

D280A108

91-21-31

Section SP04000

Page 1 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Station / WL / BL		GA	CO	Type	Diagram	Effectivity
	Bundle	Wire No.					
I SP04602		263/168/R25					ALL
	W2508	5615	24		9	21-43-21	YC060-YC064
	W2508	5672	24		9	21-43-21	YC060-YC064
	W5158	0597	24		9	21-43-21	YC060-YC064

For training purposes only!

SPLICE LIST

D280A108

91-21-31

Section SP04600

Page 1 End

Nov 12/2012



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP05006		240/208/R037					ALL
	W5514	0014	22		9	21-33-11	YL952-YL999, YN232-YR328
	W6414	0009	22		9	21-33-11	YL952-YL999, YN232-YR328
SP05008		240/208/R037					ALL
	W5514	0015	22		9	21-33-11	YL952-YL999, YN232-YR328
	W6414	0010	22		9	21-33-11	YL952-YL999, YN232-YR328

For training purposes only!

SPLICE LIST

D280A108

91-21-31

Section SP05000

Page 1 End

Nov 12/2012